

## Pre-installation Instruction

\* The installation should be carried out in accordance with local standards.

1. Make sure the sub-floor is smooth, hard, clean and dry prior to installation.
2. The sub-floor should incorporate an effective damp proof membrane.
3. Open the package, put the flooring on the ground like the following picture. (At least 20 layers)
4. The material must be allowed to acclimatize 24 hours before installation and the room temperature needs to be between 18-24°C.

2mm Homogeneous  Surfaces  
Bottom



Length : 20 Meters

Ground